



CHEVY SILVERADO BOWTIE INSERTS

Part # ABD-1401Ixxx

INSTALLATION INSTRUCTIONS

Tools Needed:

- Drill
- 3/8" Drill Bit
- Flathead Screwdriver or a Pick

Front Bowtie: These instructions are to replace the gold bowtie within the bowtie emblem. Take care not to damage the chrome border of the bowtie emblem as it will be staying on the vehicle.

1. Locate the front paper template and trim away the excess paper. Tape the template in the correct orientation over the gold insert.

WARNING, this next step can damage your vehicle if not done correctly!

2. Using the 3/8" drill bit and drill, slowly drill holes at the six hole positions, but do not drill through the entire emblem assembly, only the layer of the gold insert.

3. The gold insert should be able to be pulled out using your fingers or small screw driver or pick.

4. Make sure the surface we will be putting the new insert into is free of any debris or hanging chips or burrs and is clean enough for the tape to stick.

5. Now take your new front insert and familiarize yourself with the orientation for the correct fit. Next take the backing of the adhesive off the new emblem and align it as you did previously. Apply pressure for about 2 minutes to ensure a good bond of the tape.

6. Wipe down and enjoy.

7. Rear inserts will be done with the same process. **REMEMBER, you can damage your tailgate if you drill through too far!**

AMERICAN BROTHER DESIGNS

www.americanbrotherdesigns.com



