



## Dodge Challenger 2015-present Int. Knob Kit

ABD-3214XXX

### INSTALLATION INSTRUCTIONS

#### Tools Needed:

- Rag
- Channel locks
- Flat head screw driver

Take care not to scratch your new knob covers during this installation. While sitting in the car, familiarize yourself with the 7 knobs, buttons, pins or bezels which will get a new cover, pin or bezel. These include:

- 1 fan control knobs located in the center of the dash below the two radio tuner knobs this is also the bigger of the three covers - These covers are installed by pressing onto the knob until completely seated.
- 2 radio tuner knobs located in the center of the dash above the fan control - These covers are installed by pressing onto the knob until completely seated.
- 2 door lock bezels these are located on each door - These bezels will need to be removed first before removing the door lock pin. Carefully slide a flat head screw driver under bezel (careful not to damage material surrounding bezel) gently pry lifting plastic bezel out of door. Leave new bezel to the side and move to next step.
- 2 door lock pins located on each door - Once your previous door lock bezel is removed you will need to remove the factory door lock pin. To remove the door lock pin place a rag over the pin and grab the pin with your channel locks, you will need to grab tightly so you can un-screw the pin. (This step can damage your factory pin). Once Pin has been un-screwed take your new pin and thread until it bottoms out. Take your new bezel and press down over the pin into the door. Your installation should be complete, now enjoy!

[www.americanbrotherdesigns.com](http://www.americanbrotherdesigns.com)