



Truck Interior Knob Kit

ABD1414xxx

INSTALLATION INSTRUCTIONS

Tools Needed:

- Channel lock or similar pliers
- Rag

Take care not to scratch your new knob covers during this installation. While sitting in the car, familiarize yourself with the 12 knobs or buttons which will get a new knob cover. These include:

- 2 climate control knobs located in the center of the dash – These covers are installed by pressing onto the knob until completely seated.
- 2 radio tuner and 1 fan control knobs located in the center of the dash – These covers are installed by pressing onto the knob until completely seated.
- 1 steering column levers located on the steering column (turn signal) – This covers are installed by pressing onto the knob until completely seated.
- 1 headlight knob located on the left side of the dash – This cover is installed by pressing on until completely seated.
- 1 four wheel drive control knob located on the left side of the dash (this knob has a witness line on the inside, while the headlight knob does not) – This cover is installed by pressing on until completely seated.
- 4 door lock pins located on the top rear of each door – These pins must be removed. With the door unlocked, window down and door open loosen the pins as you would a screw with a lefty loosen process. They can be very

difficult to budge. You may need to use the pliers with the rag wrapped over the pin so that it won't be damaged. Thread the new door lock pins onto the rods. The new lock should thread on smoothly, but is difficult to start correctly. Be careful not to cross thread the lock pin.

AMERICAN BROTHER DESIGNS

www.americanbrotherdesigns.com

1-800-617-2120